



Moose Sports Surfaces, Ltd.
2257 North Wayne Avenue, Suite 2C
Chicago, Illinois 60614
773.477.4664
773.477.8248 *fax*
www.mooseports.com

MOOSE RUBBERROLL® RECYCLED RUBBER CARE & MAINTENANCE GUIDE

The MOOSE RUBBERROLL® recycled rubber flooring, like all quality floor surfaces, requires consistent cleaning and scheduled maintenance to ensure that it stays looking great. The schedule for cleaning depends on many factors including various activities, how often the floor is used, and the volume of foot traffic on the floor. The more consistent the cleaning schedule, the better the appearance of the floor.

The following general guidelines will help to keep your new MOOSE RUBBERROLL® floor looking great. The instructions contained in this Care & Maintenance Guide are given only as guidance to our customers. Moose Sports Surfaces, Ltd. cannot accept any responsibility for loss or damage that may result from the use of this information due to variations in working conditions and/or workmanship of the installer. Users are advised to conduct their own tests for a particular application and assign installers that are familiar with this type of flooring product.

FLOOR PROTECTION

The specifier should include specification details to protect the floor post-installation and until job construction is complete, such as covering the entire floor with paper or other floor covering device (plastic, plywood, etc.) until construction is completed and thorough cleaning and maintenance can be implemented. The specifier should determine and assign the responsibility for the initial cleaning to the flooring contractor, general contractor, maintenance contractor, or owner.

INITIAL CLEANING

- a. Do NOT wash floor for at least five (5 days) after installation.
- b. Remove all surface soil, debris, sand, and grit by sweeping, dust mopping, or dry vacuuming with a dry vacuum.
- c. Scrub floor with a neutral pH (7-9) detergent such as TASKI PROFI (6-10 oz./gallon of water), using a buffer or auto scrubber with a soft nylon brush or approved pad. Avoid flooding the floor.
- d. Pick up soiled solution with a wet/dry vacuum.
- e. Rinse with clean water and vacuum up the rinse water with a wet vacuum.
- f. Allow to dry thoroughly (6-8 hours).

DAILY / REGULAR CLEANING

- a. Sweep, dust mop, or vacuum floor to remove surface soil, debris, sand, and grit.
- b. Damp mop with a microfiber mop or auto-scrub using an approved pad or nylon brush with a neutral pH (7-9) detergent such as TASKI PROFI (6-10 oz./gallon of water).
- c. Allow floor to dry thoroughly (6-8 hours)

HEAVY SOIL / RESTORATIVE MAINTENANCE

- a. Remove as much surface soil, debris, sand, and grit as possible by sweeping, dust mopping, or dry vacuuming.
- b. Heavy Scrub floor with a neutral pH (7-9) detergent such as TASKI PROFI (10-16 oz./gallon of water) or TASKI ice-it using a buffer or auto scrubber with a TASKI black pad.
- c. Pick up soiled solution with a wet vacuum.
- d. Rinse with clean water and vacuum up the rinse water with a wet vacuum.
- e. Allow to dry thoroughly (6-8 hours).

OTHER

- a. Walk-off mats must be used at all doorways and openings to clean abrasive grit and contaminants from shoes.
- b. Do not use spikes on your MOOSE RUBBERROLL® floor.

MOOSE SPORTS DOES NOT PROVIDE CLEANING PRODUCTS.

Please contact Diversey, Inc. directly (contact info below) as they will be able to locate local distributors of their products, provide technical information and cleaning demonstrations.

Diversey, Inc.

www.diversey.com

Customer Service & Technical Support: 800-842-2341